

DATA SHEET

EUROCONE CONNECTOR

1. DESCRIPTION AND USE

The connector is used in underfloor heating systems to connect the PE-X/PE-RT pipes to the distributor-manifold kit connections.



2. TECHNICAL CHARACTERISTICS

| Internal code | D _{pipe} | Connection |
|---------------|-------------------|------------|
| NEOCON16 | 16x2.0 mm | 3/4 |
| NEOCON17 | 17x2.0 mm | 3/4 |

Components:

- nut
- clamping ring
- pipe adapter with O-ring sealing gaskets

3. INSTALLATION

- cut the PE-X/PE-RT (cut perpendicularly to the pipe and remove any burrs)
- insert the nut
- insert the clamping ring
- insert the pipe adapter
- connect the nut to the eurocone connection located on the bar of the distributor/manifold kit.

4. WARRANTY PERIOD

The warranty period is 24 months from the date of delivery, provided that the customer/user fully complies with the transport, handling and mounting rules.

